

# Instructions for Iron On Images

CB

THE CLEVER BAGGERS



1. Remove the tracing paper and place the transfer onto your chosen textile. The shiny plastic backing needs to be facing up. You can cut around each shape and place them in different positions if you wish.

2. Set your iron to the recommended temperature for the textile. Run iron firmly over the design for 10 - 20 seconds or until plastic backing is distorted. Be very careful not to burn the fabric or melt the plastic. A sheet of grease proof paper can also be used over the design and fabric for extra protection.



3. Slowly remove the plastic backing when cooled and to check the transfer is stuck and re-apply the plastic over the design if it hasn't. Please recycle the backing if available in your area.

**Not recommended for young children** and older children must be supervised.

The Clever Baggers Ltd, 5 Four Crosses Business Park,  
Llanymynech, SY22 6ST