

Instructions For Iron On Sheets



1. Cut your design(s) out of the sheet using a craft knife or scissors. If using a knife, cut into the matt side and remove any unwanted parts from the backing.

2. Place the design on to your chosen textile and make sure the shiny side is facing up.



3. Set your iron to the textile recommended temperature. Run iron firmly over the design for 10 - 20 seconds or until plastic backing is distorted. Be very careful not to burn

the fabric or melt the plastic. A sheet of grease proof paper can also be used over the design for extra protection.

4. Slowly remove plastic backing when cooled and recycle. Re-apply plastic over the design, and re-heat if it hasn't stuck.



Not recommended for young children.
Older children must be supervised.

**The Clever Baggers Ltd, 5 Four Crosses
Business Park, Llanymynech, SY22 6ST**

